

marantz®

Super Audio CD / Blu-ray Disc Player **UD5007**

Getting Started

Mise en route

Antes de empezar

Welcome

Thank you for choosing a marantz player.
This guide provides step-by-step instructions for setting up your player.

If you have setup problems:

If you need additional help in solving problems, contact marantz customer service in your area.

For details, see the marantz homepage. www.marantz.com

1-855-ONE-MARANTZ

1-855-663-6272

Call for Assistance: 9:00AM to 8:00PM M-F E.S.T.









For frequency asked questions please visit

<http://marantz.custhelp.com/app/answers/list>




For US and Canada only

Before You Begin

What's In the Box

 <p>Remote control unit</p>	 <p>Batteries</p>	 <p>HDMI cable</p>
 <p>Player</p>		 <p>Power cord</p>
 <p>Warranty card (for USA / for CANADA)</p>	 <p>RECYCLING SHEET</p>	 <p>Safety Instructions</p>
 <p>Remote control cable</p>	 <p>Getting Started</p>	 <p>Owner's Manual</p>

Required for setup

 <p>TV</p>	 <p>HDMI cable</p>
 <p>Receiver</p>	 <p>Ethernet cable</p>



Note that the illustrations in this manual is for explanation purposes and may differ from the actual unit.

Setup Steps

There are five steps to the setup process.

1 Install batteries in the remote control unit


2 Connect the player to your device

3 Turn on the power


4 Insert the disc and begin playback

5 Playback of Internet content


1 Install batteries in the remote control unit



Batteries




2 Connect the player to your device




3 Turn on the power

1 Turn on player.




2 Turn on receiver.

Select the appropriate HDMI input on your receiver.






3 Turn on the TV.

Select the appropriate HDMI input on your TV.




TV remote control unit

4 Insert the disc and begin playback




5 Playback of Internet content

① Network connection



② Playback




Owner's Manual

The included CD-ROM contains an Adobe PDF version of the full owner's manual for the player.
Please reference this manual for more details about the setup and operation of the player and its features.


NOTE

The contents of the included CD-ROM cannot be viewed using this player.

1 Insert the disc into your PC.



2 Follow the screen or double click on the PDF file.



www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

marantz[®] is a registered trademark.