


marantz®




MODEL 40n | Network Integrated Amplifier

QUICK START GUIDE


Before you begin

What's in the box

Quick Start Guide



Network Integrated Amplifier



Safety Instructions



Power cord



Cautions on Using Batteries



Remote control (RC005PM)



Notes on radio



2× R03/AAA batteries



External antennas for Bluetooth®/Wi-Fi® connectivity



Required for setup

Speakers




Speaker cables



Mobile device



Wi-Fi router and Internet connection



Optional

HDMI® cable




Ethernet cable



Setup

1 Connect the antennas

- 1 Place the antenna squarely over the antenna terminal in the upper-left and upper-right corner of the rear panel.
- 2 Turn the antenna clockwise until it is fully connected.
- 3 Rotate the antenna upwards for the best possible reception.




NOTE

The antennas are required for both Bluetooth and Wi-Fi functions.


Optional

If you are connecting MODEL 40n to a wired network, connect an Ethernet cable (not included) between the amplifier and your router. Do not connect the Ethernet cable if you are connecting the amplifier to a wireless network.



2 Connect your speakers

Connect your speaker cables between the MODEL 40n and your speakers.




3 Connect TV audio (optional)

- 1 Connect one end of the HDMI cable to the TV port labeled "ARC".
- 2 Connect the other end of the HDMI cable to the HDMI ARC port on the back of the MODEL 40n.


NOTE

- The TV connection is used to pass audio to the MODEL 40n from your TV's built-in sources (tuner, smart TV apps, etc.) and HDMI devices connected to your TV. The MODEL 40n does not generate any video output.
- Make sure your TV is set to output only 2ch PCM audio. Dolby Digital and DTS audio are not supported.




4 Connect to power

Connect the power cable between the MODEL 40n and a wall outlet.




5 Install batteries in the remote control



6 Turn the MODEL 40n on

Press the power on/standby button.



7 Use the HEOS app to complete MODEL 40n setup

- 1 Go to the Apple App Store, Google Play or Amazon App Store and search for "HEOS" to download and install.



- 2 Launch the HEOS app and follow the instructions in the app.




8 Add device

If you already have the HEOS app and have setup at least one HEOS built-in device, please follow the steps below to add the MODEL 40n to your wireless network.

- 1 Select the Settings  icon in the upper-left corner of the main "Music" menu to display the Settings menu.




- 2 Select "Add Device" from the HEOS app's Settings menu and follow the instructions:




Playing music - Bluetooth

1 Press Bluetooth to select Bluetooth.


When you use it for the first time, the amplifier automatically enters pairing mode and "Bluetooth Pairing..." appears on the display.




2 Activate Bluetooth on your mobile device.



3 Select "Marantz MODEL40n" from the Bluetooth device list.



4 Play music using any app on your device.



 To pair with other Bluetooth devices, press and hold Bluetooth on the remote control until "Bluetooth Pairing..." is displayed on the unit.

Contact Marantz

 **00800-43674357**

We hope you will enjoy your Marantz product for years to come. If you ever have any question or need any support, just get in touch via the free helpline. We are happy if you are happy.

In case you can't reach the helpline please check the support section on **www.marantz.com** for more information.


Owner's manual

Refer to the online manual for other functions information and operation procedure details.

manuals.marantz.com/MODEL40n/EU/EN/



Online manual



EN

DE

FR

IT

ES

NL

SV

RU

PL

Trademark information



Apple, AirPlay, iPad, iPad Air, iPad Pro and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. The trademark "iPhone" is used in Japan with a license from Aiphone K.K.

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards.



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by D&M Holdings Inc. is under license. Other trademarks and trade names are those of their respective owners.



The Wi-Fi CERTIFIED logo is a registered trademark of the Wi-Fi Alliance. Wi-Fi Certification provides assurance that the device has passed the interoperability test conducted by the Wi-Fi Alliance, a group that certifies interoperability among wireless LAN devices.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing, LLC in the United States and other countries.



www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

marantz[®] is a registered trademark.